

Heat Shield Spacer Kit

1. Support your shield 1 inch above the floor. Rest on wood blocks or similar spacing material.
2. Lightly work anchor holes 16 inches apart around perimeter of shield. Locate one anchor each corner. Do not place any anchors directly behind heating unit.
3. Place wall shield in position and drill 1/4 inch holes at marked locations around perimeter of shield drilling at least 1 inch into the wall at the same time.
4. When all ten holes are drilled, remove shield.
5. Insert one wall anchor into each drilled hole in the wall. Increase hole depth if necessary.
6. Reposition shield and align holes.
7. Insert screws through shield, ceramic spacers and into wall anchors. Do all four corners first. Do not tighten screws securely until all screws are in place.
8. When all screws are in place, tighten the four corners screws first, then the rest.
9. Remove supports indicated in Step 1.

1. 防熱板に使用する不燃材の板（アルミ板など）を用意します。防熱板を床から1インチほど浮かせたいので、1インチほどの厚みの支え（木のブロックなど）の上に載せます。
2. 防熱板の周囲に16インチ（40センチ）間隔でアンカー用の穴の位置を決めて印を付けます。四隅に1つのアンカーを配置します。薪ストーブの真後ろにはアンカーを配置しないでください。
3. 防熱板を所定の位置に置き、手順2.で印を付けた位置に1/4インチ（6.35ミリ）の穴を開けます。壁の同じ位置にドリルで深さ1インチの穴を開けます。
4. 10個の穴がすべて開けられたら、一旦防熱板を外します。
5. 壁に開けた穴にアンカーを挿入します。
6. 防熱板の穴の位置と合わせます。
7. 防熱板と壁の間にスペーサーを配置し、壁アンカーにネジを通します。最初に四隅からビス留めします。すべてのネジが収まるまではきつく締めないでください。
8. すべてのネジの位置を合わせたら、最初に四隅のネジを締めて、残りのネジを締めます。
9. 手順1で使った支えを外します。